

V1.02 Build 03

- Changed the name of "Active Power Reduction Gradient with Time" setting to be "Active Power Ramp Rate".

v1.01 Build 01

- AI-Version: XW+ Password Protected Inverter Output menu "Output Voltage L-N" setting removed and replaced with "AC Output Calibration" setting (persistent after reboot now).
- Fixed bug where status bar clear faults/warnings would clear all the event logs, warning logs, and fault logs.
- Updated CSW Status screen to look at different message for AC Input. Ensure you have the latest CSW firmware for the message to display correctly.

v1.00 Build 76

- AI-Version: Updated the resolution of Output Voltage in the Inverter Output menu from integer to 2 decimal places.
- Added Bulk Termination Voltage to the Battery settings for the XW
- Added Float Termination Voltage to the Battery settings for the XW

Float - Custom: 48.0 - 54.0

Float - Li-Ion: 44.0 - 54.0

Bulk Term Volt - Custom: 50.0 - 54.0

Bulk Term Volt - Li-Ion: 42.0 - 57.6

v1.00 Build 73

- Bug fix for legacy XW Configuration Screens
- Bug fixes for XW Device Screen arrow directions



Conext Configuration Tool Release Notes

150-0260-03-00, 150-0261-03-00

v1.00 Build 64

- Updated Advanced Features for the CSW+

v1.00 Build 63

Initial Release for re-branded software.

- Numerous bug fixes.
- New menu layout.
- Added support for XW+ and CSW.
- Added Wizard to support XW+ Multi-Cluster Configuration
- Changed CAN-USB dongle
- New drivers for Legacy CAN-USB dongle.